

INSTALLING YOUR E-way® TAG



CAR



- > The best location is attached to the windscreen behind the rear vision mirror.
- > If there is insufficient room then locate adjacent to the rear vision mirror at the top of the windscreen.
- > If there is any metal such as external sun visors, ladders, etc, above the tag it will need to be fitted lower down the windscreen.
- > Some windscreens may contain metal to activate features such as rain detectors for automated wipers etc. Metalised windscreens can interfere with the performance of the tag. Please ensure you consult your user guide to determine the exact location of an unmetallised section on your windscreen to correctly install the tag.
- > For split windscreens fit the tag left of the join.

IMPORTANT TIPS TO CONSIDER WHEN INSTALLING YOUR TAG

- > Position your vehicle out of direct sunlight during installation. Clean the area of the windscreen where the bracket is to be fitted, with the wipe provided and allow to dry.
- > Carefully trial tag bracket (without removing adhesive tape), to check the tag will fit correctly in the space. The tag should not be hit by loose objects, or the driver's vision obstructed.
- > When correctly fitted, the E-way® logo and telephone number will face inwards.

Should you experience installation difficulties, please contact our Customer Service Call Centre on 1300 555 833

INSTALLING YOUR E-way® TAG



TRUCK



VERTICAL WINDSCREENS

- > Attach your tag to the bottom of the windscreen in the middle. If there is any metal such as stone guards etc. attach your tag further up the windscreen to ensure clear detection by our readers.



SLOPED WINDSCREENS

- > Attach your tag to the windscreen behind the rear vision mirror. If there is any metal such as external sun visors or over hanging ladders, attach your tag further down the windscreen.

Prior to installation, please read **IMPORTANT TIPS TO CONSIDER WHEN INSTALLING YOUR TAG** on the reverse